

Instruction Manual

Air die grinders





FEATURES

- · Ultra-accurate concentricity
- Patented ergonomic grip handle-textured rubber grip handle helps ease user's tiredness, maintains a comforable temperature holds and insulate vibration
- Power/Speed regulator allows for easy RPM adjustment Twin-Bearing design keeps spindle run smoothly

Operator's Instruction

- 1. Cautions for use
- 1-1 Air pressure

speed, sis an

Maximum performance is displayed at the proper sanding speed, obtainable at a gauge pressure of 6.2 bar. Range-wise, this is an air pressure from 5 to 7 bar (70 to 100 psi)

1-2 Air line

Use a 3/8" air hose between the compressor and the tool. Compressed air is cooled and it's water content separated, as soon as the air leaves the compressor. Recoil



A portion of the water content, however, is condensed in the piping, and can enter the tool mechanism, and may cause trouble. So, install an air filter and an oiler between the compressor and the tool. Use a 3 HP or larger compressor for each sander. $D_{rainage}$

1-3 Air hose

Clean the hose with a blast of compressed air before connecting the hose to air tool. This will prevent both moisture and dust within the hose from entering the tool and causing possible rust or malfunction. To compensate for unusually long hose (over 25 ft), the line pressure should be increased accordingly.

1-4

The approved eye protector, ear-muff, mouth-muffle, and gloves should be worn when operate this tool.

1-5

The working place shall be well ventilated.

1-6

Release the on-off device in the case of energy supply failure.

2. Operation, adjusting and replacing method

2-1 How to install or remove an insert tool

The figure below indicates how to fasten and loose an insert tool. Before using this tool, make sure that the insert tool is fixed in the collet very tightly.



Before using the tool check the weariness of the insert tool in order to increase the effciency and safety.



For the sake of safety, put it on hanger or on a soft flat pad when it's not in use.

2-3 Replace and adjusting

There is no user serviceable part inside this tool. Please send the tool to a qualified service center to repair or/and replace worn parts.

3. Maintenance

3-1 Lubrication

Before connecting the hose, apply 4 or 5 drops of spindle oil at the air inlet. Use of a thicker oil can lead to reduced performance or malfunction.

If a thicker oil is used by accident, wipe it away immediately. Also every 3 or 4 hours of operation, oiling is necessary.

3-2 Storage

Avoid storing the tool in a location subject to high humidity. If the tool is left as it is used, the residual moisture inside the tool can cause rust. Before storing and after operation, oil the tool at the air inlet with spindle oil and run it for a short time.

3-3 Disposal

Before disposing of damaged tool, check with your state Environmental Protection Agency to find out about special restrictions on the disposal of tool or return them to a KRAFTWERK certified service center for recycling.

3-4 Ordering service parts

For further operational and handling information or for replacement of parts and components, contact the sale agent from whom you purchased the tool or the service division of our company.

Note: In ordering parts and components, give each part number, name and quantity.

WARNING

- 1. This tool is not insulted for coming into contact with electric power source.
- It is forbidden to use this tool in explosive atmospheres and do not put any combustible material near the work piece since it will emit spark, dust, and/or fumes when working in certain material.
- 3. Prevent long hair or loose clothing from drawing in while operate this tool.
- 4. Never carry the tool by hose and beware of a whipping compressed air hose.
- 5. The workpiace shall be fixed by proper device.
- 6. Keep your body balance and beware of the fall of the severed workpiece.
- 7. Use only the suggested shaft diameter of the insert tool. Do not use the cutting-off wheels and routing cutter wheels as the insert tool.
- 8. The allowed rotating speed of the insert tool shall higher than the die grinder. Also note the fact that the allowed rotating speed of the mounted point must be lower due to the increase of the shaft length between the end of the collet and the mounted point (overhang). Make certain that the minimum gripping length is 10 mm.



- D = diameter of mounted point
- T = length of mounted wheel
- $L_0 = overhang$
- s = diameter of shank
- L₂ = gripping length

- Excessive air pressure not only reduce the service life of this tool but also increase the danger. It is better to use the pressure regulator to control the air pressure being supplied to the tool.
- 10. It remains rotating for few second after releasing the lever.

Air Die Grinder



	Art. 3840	Art. 3841	Art. 3842
Free Speed (RPM)	25,000	22,000	18,000
Air Pressure (PSI)	90	90	90
Air Consumption (CFM)	2.6	3.5	3.5
Air Inlet (NPT,PT)	1/4"	1/4"	1/4"
Hose Size (INCH)	3/8"	3/8"	3/8"
Overall Length (INCH)	6.1" (155 mm)	7" (180 mm)	7" (180 mm)
Horsepower (HP)	0.3	0.5	0.5

Art.	Vibration	Noise	Remark
	EN ISO 28927-12:2012	EN ISO 15744:2008 Sound Pressure level 80 dB	
3840	No-load: 0.5 m/s²	Sound power level 90 dB	
		Instantaneous sound Pressure 96 dB	
	EN ISO 28927-12:2012	EN ISO 15744:2008 Sound Pressure level 80 dB	Should wear an approved
3841	No-load: 0.5 m/s²	Sound power level 87 dB	operating this tool
		Instantaneous sound Pressure 90 dB	
	EN ISO 28927-12:2012	EN ISO 15744:2008 Sound Pressure level 86 dB	
3842		Sound power level 90 dB	
	No-load: 0.5 m/s²	Instantaneous sound Pressure 110 dB	

Test result according to EN ISO 11148-9

Art. 3840



No	Art.	Description	Qty	No	Art.	Description	Qty
1	3840-01	SCREW	1	17	3840-17	REAR PLATE	1
2	3840-02	0-RING (P12)	1	18	3840-18	SPING PIN	2
3	3840-03	0-RING (P8)	2	19	3840-19	ROTOR BLADE	4
4	3840-04	AIR REGULATOR	1	20	3840-20	ROTOR	1
5	3840-05	SPRING	1	21	3840-21	CYLINDER	1
6	3840-06	VALVE STEM BUSHING	1	22	3840-22	CONE MUFFLER	1
7	3840-07	VALVE STEM	1	23	3840-23	BEARING SPACER	1
8	3840-08	0-RING (3.5X1.4)	1	24	3840-24	FRONT PLATE	1
9	3840-09	AIR INLET	1	25	3840-25	BEARING (608ZZ)	2
10	3840-10	EXHAUST SLEEVE	1	26	3840-26	WASHER	1
11	3840-11	0-RING (26.7X1.78)	1	27	3840-27	CLAMP NUT	1
12	3840-12	SPRING PIN	1	28	3840-28	SPINDLE	1
13	3840-13	LEVER	1	29	3840-29	COLLET	1
14	3840-14	PROTECTING RUBBER	1	30	3840-30	COLLET NUT	1
15	3840-15	HOUSING	1	31	3840-31	STOP SPANNER (14MM)	1
16	3840-16	BEARING (696ZZ)	1	32	3840-32	STOP SPANNER (19MM	1

WE RESERVE THE RIGHT FOR ANY DESIGNING CHANGES TO THE PARTS AND WITHOUT ANY NOTICEMENT IN ADVANCE.

Art. 3841



No	Art.	Description	Qty	No	Art.	Description	Qty
1	3841-01	SCREW	1	17	3841-17	REAR PLATE	1
2	3840-02	0-RING (P12)	1	18	3841-18	SPING PIN	2
3	3840-03	0-RING (P8)	2	19	3841-19	ROTOR BLADE	4
4	3841-04	AIR REGULATOR	1	20	3841-20	ROTOR	1
5	3840-05	SPRING	1	21	3841-21	CYLINDER	1
6	3840-06	VALVE STEM BUSHING	1	22	3841-22	CONE MUFFLER	1
7	3841-07	VALVE STEM	1	23	3840-23	BEARING SPACER	1
8	3840-08	0-RING (3.5X1.4)	1	24	3841-24	FRONT PLATE	1
9	3840-09	AIR INLET	1	25	3840-25	BEARING (608ZZ)	2
10	3841-10	EXHAUST SLEEVE	1	26	3841-26	WASHER	1
11	3841-11	0-RING (26.7X1.78)	1	27	3841-27	CLAMP NUT	1
12	3840-12	SPRING PIN	1	28	3840-28	SPINDLE	1
13	3840-13	LEVER	1	29	3840-29	COLLET	1
14	3841-14	PROTECTING RUBBER	1	30	3840-30	COLLET NUT	1
15	3841-15	HOUSING	1	31	3840-31	STOP SPANNER (14MM)	1
16	3840-16	BEARING (696ZZ)	1	32	3840-32	STOP SPANNER (19MM)	1

WE RESERVE THE RIGHT FOR ANY DESIGNING CHANGES TO THE PARTS AND WITHOUT ANY NOTICEMENT IN ADVANCE.

Art. 3842



1	3841-01	SCREW	1
2	3840-02	0-RING (P12)	1
3	3840-03	0-RING (P8)	2
4	3841-04	AIR REGULATOR	1
5	3840-05	SPRING	1
6	3840-06	VALVE STEM BUSHING	1
7	3841-07	VALVE STEM	1
8	3840-08	0-RING (3.5X1.4)	1
9	3840-09	AIR INLET	1
10	3841-10	EXHAUST SLEEVE	1
11	3841-11	0-RING (26.7X1.78)	1
12	3840-12	SPRING PIN	1
13	3840-13	LEVER	1
14	3841-14	PROTECTING RUBBER	1
15	3841-15	HOUSING	1
16	3840-16	BEARING (696ZZ)	1
17	3841-17	REAR PLATE	1
18	3841-18	SPING PIN	2
19	3841-19	ROTOR BLADE	4
20	3841-20	ROTOR	1

No	Art.	Description	Qty
21	3841-21	CYLINDER	1
22	3841-22	CONE MUFFLER	1
23	3840-23	BEARING SPACER	1
24	3841-24	FRONT PLATE	1
25	3840-25	BEARING (608ZZ)	2
26	3842-26	BEVEL GEAR (18T)	1
27	3842-27	NUT	1
28	3842-28	CLAMP NUT	1
29	3842-29	ANGLE HOUSING	1
30	3842-30	OIL CUP	1
31	3842-31	BEVEL GEAR (20T)	1
32	3842-32	BEARING (6000ZZ)	1
33	3842-33	SHAFT	1
33A	3842-33A	SNAP RING	1
34	3842-34	CLAMP NUT	1
35	3840-28	SPINDLE	1
36	3840-29	COLLET	1
37	3842-37	KEY	1
38	3840-31	STOP SPANNER (14MN)
39	3840-32	STOP SPANNER (19MN)

WE RESERVE THE RIGHT FOR ANY DESIGNING CHANGES TO THE PARTS AND WITHOUT ANY NOTICEMENT IN ADVANCE. 9

MWARNING RISK OF EYE OF HEAD INJURY



WHAT COULD HAPPEN	HOW TO PREVENT IT
Air powered equipment and power tools are capable of propelling materials such as fasteners, metal chips, sawdust and other debris at high speed which could result in serious eye injury.	Always wear ANSI approved Z87.1 safety glasses with side shields. Never leave operating tool unattached. Disconnect air hose when tool is not in use.
Compressed air can be hazardous. The air system can cause injury to soft tissue areas such as eyes, ears, etc. Particles or objects propelled by the stream can cause injury.	For additional protection use an approved face shield in additionto safety glasses.
Tool attachments can become loose or break and fly apart propelling articles at the operator and others in the work area.	Make sure that any attachments are securely assembled.

MARNING RISK OF FIRE OR EXPLOSION



	-
WHAT COULD HAPPEN	HOW TO PREVENT IT
Abrasive tools such as sanders and grinders, rotating tools such as drills, and impact tools such as nailers, staplers, wrenches, hammers and reciprocating saws are capable of generating sparks, which could result in ignition of flammable materials.	Neveroperate tools near flammable substances such as gasoline, napithha, cleaning solvents, etc. Work in a clean, well-ventilated area free of combustible materials. Never use oxygen, carbon dioxide or other bottled gases as a power source for air tools.
Exceeding the maximum pressure rating of tools or accessories could cause an explosion resulting in seriou s injury.	Use compressed air regulated to a maximum pressure at or below the rated pressure of any attachments. Never connect to an air source that is capable of exceeding 200 psi. Always verify prior to using the tools that the air source has been adjuste d to the rated air pressure range.

WARNING RISK OF LOSS OF HEARING



WHAT COULD HAPPEN	HOW TO PREVENT IT
Long term exposure to noise produced from the operation of air tools ca lead to permanent hearing loss.	Always wear ANSI S3.19 hearing protection.

MARNING INHALATION HAZARD



WHAT COULD HAPPEN	HOW TO PREVENT IT
Abrasive tools, such as grinders, sanders and cut-off tools generate dust and abrasive material, which can be harmful to human lungs and respiratory system.	Always wear properly fitting facemask or respirator when using such tools.
Some material such as adhesives and tar contain chemicals whose vapors could cause serious injury with prolonged exposure	Always work in a clean, dry, well ventilated area.

WARNING RISK OF INJURY



WHAT COULD HAPPEN	HOWTO PREVENT IT
A tool left unattended, or with the air hose attached,	Remove air hose when tool is not inuse and store
can be activated by unauthorized persons leading to	tool in secure location away from reach of childne
their injury or injury to others.	and untrained users.
Air tools can propel fasteners or other materials	Use only parts, fasteners and accessories
throughout the work area.	recommended by the manufacturer.
	Keep work area clean and free of clutter. Keep
	children and others away from tool while is in
	operation.
	Keep work area well lit.
Air tools can become activated by accident during	Remove air hose to lubricate or add grinding
maintenance or tool changes.	attachments, sanding discs, drills, etc. to the tool.
	Never carry the tool by hose
	Avoid unintentional starting. Don't carry hook-up
	tool with finger on trigger.
	Only a authorized service representative should do
	repair servicing.
Air tools can cause the workpiece to move upon	Use clamps or other devices to prevent movement.
contact, leading to injury.	
Loss of control of the tool can lead to injury to self or	Never use tool while using drugs or alcohol.
others.	Don't overreach. Keep proper footing and balance.
	Keep handles dry, clean and free from oil/grease.
	Stay alert. Watch what you are doing. Use common
	sense. Do not operate tool when you are tired.
Poor quality, improper or damaged tools such as	Always use tool attachments rated for the speed of
grinding wheels, chisels, sockets, drills, nailers,	the power tool.
staplers, etc. can fly apart during operation, propelling	Never use tools, which jave been dropped, impacted
particles throughout the work area causing serious	or damaged by use.
injury.	Use only impact grade sockets on an impact wrench.
	Do not apply excessive force to the tool let the tool
	perform the work.

MARNING RISK OF ENTANGLEMENT



WHAT COULD HAPPEN	HOW TO PREVENT IT
WHAT LOULD HAPPEN Tools which contain moving elements, or drive other moving parts, such as grinding wheels, sockets, sanding discs, etc., can become entangled in hair, clothing, jewelry and other loose objects, resulting in severe injury.	HOW NO PREVENTIN Never wear loose fitting clothes or apparel that contains loose straps or ties, etc., which could become entangled in moving parts of the tools. Removeany jewelry, watches, identifications, bracelets, necklaces, etc., which might become caught by the tool. Keep hand aways from moving partsTie up or cover long hair. Always wear proper fitting clothing and other safety
	equipment when using the tool.

🗥 WARNING RISK OF CUT OR BURNS 🎾 👫

WHAT COULD HAPPEN	HOW TO PREVENT IT
Tools that cut, shear, drill, staple, punch, chisel, etc.	Keep the working part of the tool away from hands
are capable of causing serious injury.	and body.

WARRANTY

We do not take responsibility for any damage caused by misuse or any use that is not in compliance with the safety standards described herein.

CUSTOMER SERVICES

Contact your local importer of your specialized dealer to obtain address of our service department.

FROM DATE OF PURCHASE RECEIPT 2 YEAR GUARANTEE ON MATERIAL OR PRODUCTION DEFECTS



KRAFTWERK Europe AG Mettlenbachstrasse 23 CH-8617 Mönchaltorf Switzerland Tel. +41-44 949 40 50 KRAFTWERK Sàrl. 25, rue du Stade F – 67870 Bischoffsheim France Tel. +33-388 48 64 50

www.kraftwerktools.com